


WICKEDBONE

QUICK START GUIDE

Welcome to Wickedbone



① LED Indicator Light


② Removable Tires

③ Micro USB Charging Port


Quick Start



Download Wickedbone App
on Google Play or App Store



Charge your Wickedbone
by connecting it to a USB port



Open the App and
touch to connect

 Charging  Fully Charged

(The LED indicator light indicates the charge status)



Wickedbone User Manual

Review the user manual before using Wickedbone. Go to www.cheerble.com/wickedbone or open the Wickedbone app. To view or download the user manual. Retain documentation for future reference. The manual is subject to change without prior notice.

Safety and Handling

See "Safety and Handling Information" in the *Wickedbone User Manual*. To avoid injury or harm, please read all safety information and operating instructions in the user manual carefully before you or your child use Wickedbone, follow the operating instructions. Wickedbone is not suitable for use by children under 8 years of age. Wickedbone has small parts inside its shell, which may present a choking hazard to small children and pets. Keep Wickedbone and its accessories away from small children. Do not swallow Wickedbone and its accessories to avoid damage or injury. Ensure that there are no safety hazards in Wickedbone such as cracked, damaged or otherwise broken parts when operating.

Battery

Wickedbone has a built-in battery that is not removable. Do not attempt to replace the battery yourself to avoid damaging the battery, which could cause overheating, fire, and injury. Please see "Battery Safety Guidelines" in the *Wickedbone User Manual* for important usage information. Note that Wickedbone battery must be recycled or disposed of separately from household waste. Dispose of batteries according to your local environmental laws and guidelines.

Health Considerations

See "Health Considerations" in the *Wickedbone User Manual*.

Maintenance & Care

Wickedbone is not waterproof, do not drive it through any kind of water or wash it. See "Maintenance & Care" in the *Wickedbone User Manual*.

One-Year Limited Warranty Summary

Shenzhen Cheerble Technology Co., Ltd. ("Cheerble") assures the initial purchaser, there will be no materials and workmanship defects in Cheerble hardware product ("product") for one year from the date of original retail purchase under normal use. Cheerble does not warrant against normal wear and tear, nor damage caused by accident or abuse. Cheerble shall not be responsible for any loss due to failure to comply with the relevant instructions for use of the product. This warranty is valid only within the jurisdiction of Cheerble or through the sale of the product by its authorized distributor or agent, or within the scope permitted by the applicable law of such jurisdiction. The available service options are dependent on the country in which service is requested and may be restricted to the original country of sale. Under applicable law, Cheerble may require you to furnish proof of purchase details before obtaining the warranty service. For the full terms and detailed information about after-sales services and warranty policy, go to www.cheerble.com/cn/support/policy. If you submit a valid claim under this warranty, Cheerble will either repair, replace, or refund your product at its own discretion. To obtain service, you must send the product to the address specified by Cheerble, and use the original packaging or provide the same degree of protection packaging. Unless prohibited by applicable law, we may charge for

shipping and handling fees. The limited warranty shall be governed by the local consumers laws.

Support

Do not attempt to service Wickedbone yourself. More support information about Wickedbone is available online at www.cheerble.com/support. You can also send email to support@cheerble.com to contact our after-sales service staff for more support.

Regulatory

This device complies with CE, FCC requirements. See "Compliance Information" in the *Wickedbone User Manual* for more detailed regulatory information, certification, and compliance marks of this device.

Trademarks

WICKEDBONE, Cheerble, and the Cheerble logo are trademarks of Shenzhen Cheerble Technology Co., Ltd.

The Bluetooth wordmark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Shenzhen Cheerble Technology Co., Ltd. is under license.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

App Store is a service mark of Apple Inc.

Google Play is a trademark of Google Inc.

Other trademarks, product, service, and company names mentioned may be the property of their respective owners.

Specifications

Model: C1702

Weight: 300 g (Battery Included)

Dimensions: 151.5 x 64 x 64 mm / 6 x 2.5 x 2.5 inches

Wireless Connection: Bluetooth 5.0, 2.4 GHz

Port: Micro USB Charging Port

Max Speed: 4 m/s

Suggested Control Distance: Up to 20 m (65 ft)

Operating Temperature: 0° to 40° C (32° to 104° F)

Battery Type: Li-Polymer

Battery Capacity: 470 mAh

Compatible Device: iOS 9.0 (or later) or Android 4.4 (or later)

Cheerble

Download the latest version from
www.cheerble.com/wickedbone

If you have any questions about this document, please contact us by
sending a message to support@cheerble.com

Copyright © 2018 Cheerble All Rights Reserved.
Printed in China.